

Maintenance Tips

Keeping your Quooker Tap looking new

We would like to ensure your tap is always kept in the best condition. As every finish requires its own special treatment, we have outlined advice below for all the different finishes.

Cleaning Instructions:

- **Polished chrome, stainless steel, nickel and gold**

Use glass cleaner and or water only with a soft cloth. Spray a small amount on a damp cloth (not directly on the tap) and then wipe the tap. Dry the tap immediately after use.

- **Black, gunmetal and rose copper**

Use only warm water and a soft cloth. Do not use (alcohol-based) cleaning products, because they damage the finish. Dry the tap immediately after use.

- **Patinated brass**

Use only warm water and a soft cloth. Do not use (alcohol-based) cleaning products, because they damage the finish. Do you want extra protection for your tap? Rub it with a layer of beeswax every 3 or 6 months. Dry the tap immediately after use and cleaning.

Descaling the tap Aerator

When the water flow becomes less strong, you can usually solve this easily by descaling the tap Aerator of your Quooker tap.

This is very simple: unscrew the metal sleeve at the end of the spout, just place the sieve in cleaning vinegar for an hour, rinse off the limescale and screw it back into place.

If the Quooker tap still does not provide an optimal water flow after the tap Aerator has been descaled, there are multiple possible steps you can take. Please [contact](#) service to see which solution fits best for your situation.

Can't get the Aerator clean anymore? Order a new one for your tap directly from Quooker

